



# Spy Walkie-Talkies

Stay in constant contact with your fellow secret agent while you shadow suspects and stake out crime scenes using your Spy Walkie-Talkies. The walkie-talkies can work over a distance of up to 3 kilometers (~1.5 miles), so one of you can be out in the field while the other remains at headquarters. With three different radio channels, you can avoid interference signals, and the flashlight function doubles as a handy investigation tool.

- **WARNING!** Not suitable for children under 3 years. Choking hazard – small parts may be swallowed or inhaled.
- **IMPORTANT!** Protect the devices from moisture. Clean them with a damp cloth and allow them to dry thoroughly before using them again.
- Do not leave the devices in direct sunlight or expose them to other sources of heat.
- Keep the packaging and instructions as they contain important information.

## 1) Using your Spy Walkie-Talkies:

- Have an adult remove the walkie-talkies from the package and install new batteries in both devices. (Section 2, images 1 and 2 further explain how.)
- Turn your walkie-talkies on by pressing the On/Off button (upper-left). The display will show a number 1.
- Press and hold the Channel button (center) for one second to change the channel. The number 1 will change to a number 2 on the display. Repeat this step to go to channel 3 and then back to channel 1, and so on. Changing the channel helps you to avoid possible interference (from radio stations, for example). Both walkie-talkies must be turned on and be on the same channel in order for you to talk to each other through them.
- Press and hold the Talk button (lower-right) while speaking. As you hold down the button, the number will flash on the display, indicating that your fellow agent can hear you. Release the button when you are done speaking so the other person can respond. If you are both pressing the Talk button at the same time, neither person will hear the other. (That's why people say "Over" into their walkie-talkies in movies and on TV. It lets the other person know it is their turn to talk.)
- Your walkie-talkies can communicate over a distance of up to 3 km (~1.5 mi) unobstructed.
- **IMPORTANT:** Because other people may be able to eavesdrop on the frequency you're transmitting on, it is important not to share anything too private over the walkie-talkie (like your address). If you hear someone else, change the channel immediately.
- If you press the Ringer button (top-right), your partner's walkie-talkie will ring, followed by your own. This way, you can signal to the other person that you have something important to say, or you can find their location without communicating verbally.
- If you're investigating in the dark, the Flashlight button (lower-left) comes in handy. Press and hold the button with the light bulb and the LED on top of the walkie-talkie lights up. You can use this to reveal your location to your partner in the dark or communicate via Morse code signals.

**Tip!** Use the clip on the back of your walkie-talkie to attach it to your belt, bag, or pocket. This way, you always have it handy when your partner calls.

## 2) Installing and Replacing the Batteries:

**IMPORTANT!** An adult should insert and change the batteries.

- First, detach the belt clip on the back of the device by opening the clamping mechanism with your fingers and pushing the clip upwards so that it slides out of the holder (see image 2). This reveals the battery compartment underneath.
- Using a Phillips-head screwdriver, loosen the screw on the walkie-talkie's battery compartment and lift off the cover. The screw will remain in the cover.
- Remove the old batteries (if applicable) and insert three new AAA batteries (1.5-volt, type LR03). Pay close attention to the correct polarity (see image 1). Close the battery compartment and screw the cover back on.
- Repeat these steps for the other walkie-talkie.

### Safety for Experiments with Batteries:

- An adult should insert and change the batteries.
- To operate the walkie-talkies, you will need six (6) AAA batteries (1.5-volt, type LR03), which could not be included in the kit due to their limited shelf life.
- Avoid a short circuit of the batteries. A short circuit can cause the wires to overheat and the batteries to explode.
- Different types of batteries or new and used batteries are not to be mixed.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

- Batteries are to be inserted with the correct polarity (+ and -). Press them gently into the battery compartment. See above.
- Non-rechargeable batteries are not to be recharged. They could explode!
- Rechargeable batteries are only to be charged under adult supervision.

### NOTES ON DISPOSAL OF ELECTRICAL AND ELECTRONIC COMPONENTS


The electronic components of this product are recyclable. For the sake of the environment, do not throw them into the household trash at the end of their lifespan. They must be delivered to a collection location for electronic waste, as indicated by the following symbol:

Please contact your local authorities for the appropriate disposal location.

### Quick Start Guide:


1. An adult must install the batteries. (See section 2.)
2. Turn on both walkie-talkies using the power button and tune them to the same channel using the button in the center. You're all set up! Now, give one to your fellow agent.
3. To speak, press and hold the button with the telephone icon.
4. Press the button with the musical note to make the other walkie-talkie ring and get your partner's attention.
5. Press and hold the button with the light-bulb icon for the flashlight function.

Image 1



Battery compartment for 3 x AAA batteries (1.5-volt, type LR03)

Image 2



Belt clip

Image 3

LED light

Channel

On/Off

Flashlight

Ringer

Talk

- Rechargeable batteries are to be removed from the toy before being charged.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Dispose of used batteries in accordance with environmental provisions, not in the household trash.
- Avoid deforming the batteries.



© 2022 Franckh-Kosmos Verlags-GmbH & Co. KG, Pfizerstrasse 5-7, D-70164 Stuttgart, Germany.

This work, including all its parts, is copyright protected. Any use outside the specific limits of the copyright law without the consent of the publisher is prohibited and punishable by law. This applies specifically to reproductions, translations, microfilming, and storage and processing in electronic systems and networks. We do not guarantee that all material in this work is free from copyright or other protection.

Layout, typesetting, packaging, and instructions: Michael Schlegel, kommuniki, Würzburg  
Cover illustration: Wolfgang Peschke, Peschke Grafik, Ostfildern

© 2022 Thames & Kosmos, LLC, Providence, RI, USA  
Thames & Kosmos® is a registered trademark of Thames & Kosmos, LLC.  
Editing: Ted McGuire and Peter Bowen  
Additional illustrations: Dan Freitas and Ted McGuire  
Packaging artwork: Dan Freitas

Distributed in North America by Thames & Kosmos, LLC, Providence, RI 02903  
Phone: 800-587-2872; Web: www.thamesandkosmos.com

We reserve the right to make technical changes.  
Printed in China / Imprimé en Chine

### FCC Part 15 Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement  
To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. For body worn operation, this device has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the device a minimum of 5 mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

### CAN ICES-3 (B)/NMB-3(B)

IC Statement: This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme NMB-003.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 5 cm de distance entre la source de rayonnement et votre corps.